

JACK E5 4 THREAD THREADING GUIDE

Follow the numbered path (1-10) to thread the machine.

(4 thread threading guide on 6 thread overlocker)







Pass the thread through the top thread guide.



Thread through the main tension assembly.




Thread through the thread guide.




Thread through the thread guides.




Thread through the thread guides and looper.




Pass the thread through the top thread guide.




Thread through the main tension assembly.



Thread through the thread guides.



Thread through the thread guides.



Thread through the thread guides and needle.

Disclaimer:
Machine can not use this thick thread , this is only for learning purposes!



LOCATION:
48 Durban Street, Cnr End Street, City and Suburban, Johannesburg.

TEL: 011 334 6759/60

EMAIL: marketing@prosewing.co.za

NOTES

- Raise the presser foot before threading.
- Make sure the thread is properly seated in the tension discs.
- Use high-quality thread for best results.